




## Connectors



Torque	Connector	H	J	K	L	oM	oN	oO	P	oR	S	T	oU	oW	oX
125	A1	65	3	28	1,5	100	140	175	M16	20	6	23,3	-	-	-
160	A2	65	3	28	1,5	100	140	175	M16	30	8	33,3	-	-	-
250	A2	65	3	28	1,5	100	140	175	M16	30	8	33,3	-	-	-
	B1	9	3	28	1,5	100	140	175	M16	-	-	-	20	40	60
400	A3	65	3	28	1,5	100	140	175	M16	40	12	43,3	-	-	-
						130	165	210	M20	40	12	43,3	-	-	-
	B1	9	3	28	1,5	130	165	210	M20	-	-	-	20	40	60

**Electric circuit diagram of actuator ESO-07 without equipment**



**Electric circuit diagram of actuator ESO-07 with position transmitter EPO**

